


INSTALLATION MANUAL


10107UV

ecodownlight




230V | SMD 2835 | 7W | IP44 | Adjustable CCT | Die cast
Complete with 180mA driver.

80
CRI



one
LIGHT



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.


INSTALLATION MANUAL

10113UV

LED
BUILT IN



UGR19




135mm

230V | SMD 2835 | 13W | IP44 | Adjustable CCT | Die cast


Complete with 300mA driver.

80
CRI




48mm

one
LIGHT





A



B

N
L



Adjustable CCT
6000K-4000K-3000K

C



D



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.

INSTALLATION MANUAL

10120UV

LED
BUILT IN




UGR19

CE

EAC

UK
CA


RoHS
COMPLIANT



190mm


230V | SMD 2835 | 20W | IP44 | Adjustable CCT | Die cast
Complete with 500mA driver.

80
CRI



55mm

one
LIGHT




A



B

N

L



Adjustable CCT
6000K-4000K-3000K

C



D



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.


INSTALLATION MANUAL

10130UV

eco downlight




UGR19





230V | SMD 2835 | 30W | IP44 | Adjustable CCT | Die cast
Complete with 700mA driver.

80
CRI



one
LIGHT



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.