


INSTALLATION MANUAL



10110CE

ecodownlight




230V | SMD 4014 | 10W | IP20 | Aluminium + PC
Complete with 250mA driver.

80
CRI



one
LIGHT




Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.

INSTALLATION MANUAL


10114CE

ecodownlight




230V | SMD 4014 | 14W | IP20 | Aluminium + PC
Complete with 300mA driver.

80
CRI



one
LIGHT



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.


INSTALLATION MANUAL

10120CE


ecodownlight




80
CRI



230V | SMD 4014 | 20W | IP20 | Aluminium + PC
Complete with 700mA driver.



one
LIGHT



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.