





# INSTALLATION MANUAL

11115G



230V | COB LED | 15W | IP20 | Adjustable beam | Aluminium  
Complete with 350mA driver.



## Warnings:


1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.

# INSTALLATION MANUAL





## 11128G



90  
CRI



230V | COB LED | 25W | IP20 | Adjustable beam | Aluminium  
Complete with 600mA driver.



### Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.