INSTALLATION MANUAL

67466A


















230V | SMD 2835 | 6W | IP20 | Aluminium


Complete with 300mA driver.

80 CRI



Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.



INSTALLATION MANUAL

67466B

















230V | SMD 2835 | 6W | IP20 | Aluminium


Complete with 300mA driver.

80 CRI



Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.



INSTALLATION MANUAL

67466C



230V | SMD 2835 | 12W | IP20 | Aluminium








Complete with 300mA driver.
















Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.

